

.....

1 : Initialization

Initialization using a Minitel **1-2**

Initialization using GENECOM **1-4**

2 : Establish the connection

Using a Minitel **2-1**

Using GENECOM **2-2**

Login password **2-3**

Extension capacity **2-5**

Definitions **2-5**

Total number of extensions **2-5**

An extension is said to be 'present' **2-5**

An extension is said to be 'phantom' **2-5**

Behaviour **2-5**

Installing a system not using administration without hardware **2-6**

Installing a system using administration without hardware **2-6**

EuroGeneris menu **2-7**

3 : Main menu

4 : Date and time



.....

5 : System administration

- Power supply **5-2**
- S0 Bus **5-3**
- Number of trunks **5-4**
- Serial port **5-5**
- Serial port assignment **5-6**
- Feature access code **5-8**
- Outset of basic cabinet to extension cabinet **5-10**
- CT2 cordless administration **5-11**
 - Base Identification Code* **5-12**
 - Cordless phone registration* **5-13**
 - Registration procedure for cordless phones **5-13**
 - Cordless phone deregistration* **5-14**
 - Manufacturer's parameters* **5-14**
- Country code **5-15**

6 : Extension administration

- Administer an extension **6-2**
 - Administration without hardware* **6-2**
 - Administer an extension* **6-3**
 - Extension button assignments* **6-7**
 - Auto-answer* **6-8**
- Extension group **6-9**
- Voice services group **6-11**
- Call coverage answer group **6-13**
- Attendant console **6-14**
- Call waiting indication **6-15**
- Access to button assignment **6-16**

7 : Trunk administration

- Administer a trunk **7-2**
 - Administration without hardware* **7-3**
 - Administer an analog CO trunk* **7-4**
- List of trunks **7-5**

.....

8 : Terminal translation initialization

9 : Routing

Incoming call distribution **9-2**

*Incoming trunk groups **9-3***

Day service incoming trunk group **9-4**

Night service incoming trunk group **9-6**

Call termination - assigned trunks to a single or several extensions **9-7**

Call termination - non assigned trunks **9-7**

*ISDN DID **9-8***

ISDN-DID parameters **9-10**

Assign ISDN-DID numbers **9-11**

Delete ISDN-DID numbers **9-14**

Display ISDN-DID numbers **9-15**

Assign ISDN-DID trunks **9-15**

Calling party number **9-16**

Add/Modify Extension nb-Calling party nb **9-17**

Delete Extension nb - Calling party nb **9-17**

Display Ext nb - Calling party nb **9-17**

Automatic CPN assignment **9-17**

Area code **9-18**

*ISDN subaddressing **9-19***

*Coverage path Extension - Don't answer **9-20***

*Coverage path Extension-Active **9-22***

*Coverage path Extension group- Don't answer **9-23***

*Coverage path Extension group-Active **9-25***

Outgoing call routing **9-26**

*Outgoing trunk groups **9-27***

*Outgoing assignments **9-28***

*Automatic route selection (ARS) **9-29***

Definitions **9-29**

Behaviour **9-29**

*ARS tables **9-30***

ARS time-of-day charts **9-31**

ARS digit analysis tables **9-32**

ARS route pattern tables **9-33**

*ARS parameters **9-34***



.....

10 : Restriction

Administer classes (COR) **10-2**

Emergency call list **10-2**

Operating hints: **10-3**

Classes of restriction (CORs) **10-3**

Administering a class **10-3**

Operating hints: **10-3**

Administer time of day plans **10-5**

11 : Miscellaneous

Change login password **11-2**

Delete system administration **11-3**

Delete all personal AD numbers **11-4**

Delete all the outgoing assignments **11-4**

Delete all the extension assignments **11-5**

Delete all the trunk assignments **11-6**

Delete a trunk group **11-6**

Re-initialize an extension **11-7**

Re-initialize the system **11-7**

Administer system wide timers **11-8**

Configure VEGA DSS **11-9**

Configure SOLARIS DSS **11-10**

Remove an extension **11-11**

Remove a trunk **11-12**

Event report **11-13**

Event report criteria **11-14**

Real-time event report **11-15**

Event report scheduled output **11-16**

12 : International requirements

United Kingdom **12-1**

Analog CO-trunks **12-1**

Analog CO-trunk board **12-1**

Power failure transfer board **12-1**

Call charge detector board **12-1**

Restriction **12-1**

13 : Index

Thanks to its smart software, the system can be connected to different national public telephone networks.

The purpose of the initialization procedure is to adapt the system to the country in which it is to be installed. This procedure **must be carried out before any other operation**.

When first started up, the system parameters are initialized for installation in France.


The available options are:

- Australia.
- Belgium.
- Czech Republic.
- Germany.
- Hungary.
- Italy.
- Luxembourg.
- Poland.
- South Africa.
- Spain.
- Switzerland.
- The Netherlands.
- United Kingdom.

Initialization using a Minitel

Applicable to France only.

1. Connect the Minitel VDU in parallel to an analog station (See Minitel instructions for use)
2. Switch on the Minitel
3. Dial **497** on either the analog station or Minitel keypad
 - Listen for the specific Minitel tone.
4. Press the «**Local Line**» button on the Minitel keypad
 - The system welcome screen appears:



5. Press «**10000**» (1 + 4 zeros)
6. Press «**Enter**»
7. Press «**1**» then «**Enter**»
8. Press «**2**» then «**Enter**»
9. Press «**9**» then «**Enter**»

```

Country code
-----
Country code : . . . . . :
FRANCE       : 0   BELGIUM           : 1
GERMANY      : 2   THE NETHERLANDS : 3
LUXEMBOURG   : 4   SPAIN            : 5
SOUTH AFRICA : 6   UNITED KINGDOM   : 7
ITALY        : 8   POLAND            : 9
CZECH REP.   : 10  HUNGARY           :11
SWITZERLAND  : 12  AUSTRALIA        :13

Administration language : .
  FRENCH      : 0   ENGLISH         : 1
  GERMAN      : 2   SPANISH         : 3

```


Initialization using GENECOM

1. Run the GENECOM program (see GENECOM instructions for use).
2. Configure the GENECOM software:
 - GENERIS version
 - Select serial port
 - Set serial port parameters (GENERIS serial port is factory-set : Data rate 9600 - Parity none - Number of stop bits 1 - Number of bits 8).
3. In GENECOM main menu, select option B "Backup / Restore".
4. Enter the Installer's login password (I0000)
 - The Backup / Restore screen appears.
5. Select option D "Country selection".
6. Select the appropriate option.
The upload is taking place. When the upload is complete, the connection to the system is dropped.

Using a Minitel

Applicable to France only.

1. Connect the Minitel VDU in parallel to an analog station (See Minitel instructions for use)
2. Switch on the Minitel
3. Dial **497** either on the analog station or the Minitel keypad
 - Listen for the specific Minitel tone.
4. Press «**Local Line**» on the Minitel keypad
 - The system welcome screen appears:



Using GENECOM

1. Run the GENECOM program (See GENECOM user's manual)
2. Configure the GENECOM software:
 - GENERIS version
 - Select serial port
 - Set serial port parameters (GENERIS serial port is factory-set : Data rate 9600 - Parity none - Number of stop bits 1 - Number of bits 8)In GENECOM main menu, select option C "GENERIS configuration"
- The system welcome screen appears:



Login password

For obvious security reasons, the system is password protected and a login password has to be entered to establish the connection. It is made-up of one letter (I or E) followed by 4 administrable figures. (See *Change login password*, page 11-2.)

The system takes two different login passwords :

- Ixxxx intended for the installer
- Exxxx intended for the end-user.

Note : The login passwords are in the form Ixxxx and Exxxx, irrespective of the administration language.

Note : The login passwords are factory-set as I0000 and E0000.

Table 1 : System administration

Screen header	Installer (Login password Ixxxx)	End-user (Login password Exxxx)
Date and time, page 4-1.	Accessible	Accessible
Power supply, page 5-2.	Accessible	Non Accessible
S0 Bus, page 5-3.	Accessible	Non Accessible
Number of trunks, page 5-4.	Accessible	Non Accessible
Serial port, page 5-5.	Accessible	Non Accessible
Serial port assignment, page 5-6.	Accessible	Non Accessible
Feature access code, page 5-8.	Accessible	Non Accessible
Outset of basic cabinet, page 5-10.	Accessible	Non Accessible
CT2 cordless administration, page 5-11.	Accessible	Accessible
Country code, page 5-15.	Accessible	Non Accessible
Administer an extension, page 6-2.	Accessible	Accessible
Extension group, page 6-9.	Accessible	Accessible
Call coverage answer group, page 6-13.	Accessible	Read only
Attendant console, page 6-14.	Accessible	Accessible
Call waiting indication, page 6-15.	Accessible	Accessible
Access to button assignment, page 6-16.	Accessible	Accessible
Administer a trunk, page 7-2.	Accessible	Accessible
List of trunks, page 7-6.	Accessible	Accessible
Terminal translation initialization, page 8-1.	Accessible	Accessible
Incoming call distribution, page 9-2.	Accessible	Accessible
Incoming trunk groups, page 9-3.	Accessible	Read only
Outgoing call routing, page 9-26.	Accessible	Read only

Table 1 : System administration

Screen header	Installer (Login password lxxxx)	End-user (Login password Exxxx)
Outgoing assignments, page 9-28.	Accessible	Read only
Administer classes (COR), page 10-2.	Accessible	Read only
Administer time-of-day plans, page 10-5.	Accessible	Accessible
Change login password, page 11-2.	Accessible	Accessible
Delete system administration, page 11-3.	Accessible	Non Accessible
Administer system-wide timers, page 11-8.	Accessible	Read only
Configure VEGA DSS, page 11-9.	Read only	Read only
Configure SOLARIS DSS, page 11-10.	Accessible	Accessible
Remove an extension, page 11-11.	Accessible	Accessible
Remove a trunk, page 11-12.	Accessible	Accessible
Event report, page 11-13.	Accessible	Non Accessible
See <i>Dial AD number</i> , in the User's manual	Non Accessible	Accessible
See <i>Display/Program AD number</i> , in the User's manual	Non Accessible	Accessible
See <i>Print an AD list</i> , in the User's manual	Non Accessible	Accessible
See <i>Label fields</i> , in the User's manual	Non Accessible	Accessible
See Administer AD group, in the User's manual	Non Accessible	Accessible
See <i>Reset AD</i> , in the User's manual	Non Accessible	Accessible
See <i>Change charge unit</i> , in the User's manual	Accessible	Accessible
See <i>CDR data</i> , in the User's manual	Accessible	Accessible
See <i>Real-time CDR report</i> , in the User's manual	Accessible	Accessible
See <i>Customized CDR report</i> , in the User's manual	Accessible	Accessible
Print configuration	Accessible	Accessible

Extension capacity

The GAL located on the processor board determines the extension capacity.

Table 2 : Extension capacity

GAL	Maximum number of extensions
none or unknown	8
GAL 16	16
GAL 32	32
GAL 128	128

The GAL located on the processor board must be changed to increase the capacity of the system.

Definitions

Total number of extensions

The total number of extensions is equal to the number of dedicated terminals (PN and PI), plus the number of S0 terminals, plus the number of analog stations, plus the number of cordless phones (CT2).

An extension is said to be 'present'

- in the case of a dedicated (PN or PI) or S0 terminal, when the terminal is connected.
- in the case of an analog station (PS), when the analog line board is mounted.
- in the case of a cordless phone, when the phone is registered.

An extension is said to be 'phantom'

when it is not present but nevertheless administered without hardware.

Behaviour

The total number of extensions is equal to the number of extensions said to be 'present' plus the number of extensions said to be 'phantom'.

Important: When extension numbers are 3-digit numbers (Feature access code, page 5-8.), the system will only identify 100 extensions and ignore the remaining. "Inoperative ext." will be displayed at the attendant console.

Installing a system not using administration without hardware

1. All the extensions said to be 'present' are identified within the system extension capacity.

Note: If the number of extensions said to be 'present' is greater than the system extension capacity, the system will only identify the first X extensions (X=maximum number of extensions).

For instance: Number of extensions said to be 'present'=20, Maximum number of extensions=16. The system will identify 16 extensions and ignore the last 4.

2. If the number of extensions said to be 'present' is lower than the maximum number of extensions, the number of extensions able to be administered without hardware is equal to the maximum number of extensions minus the number of extensions said to be 'present'.

For instance: Number of extensions said to be 'present'=20, Maximum number of extensions=32. The number of extensions able to be administered without hardware is equal to 12.

Installing a system using administration without hardware

1. All the extensions administered without hardware are identified within the system extension capacity.

Note: If the number of extensions administered without hardware is greater than the system extension capacity, the system will only identify the first X extensions (X=maximum number of extensions).

For instance: Number of extensions administered without hardware=20, Maximum number of extensions=16. The system will identify 16 extensions and ignore the last 4.

2. If the number of extensions administered without hardware is lower than the maximum number of extensions, the number of extensions said to be 'present' identified by the system is equal to the maximum number of extensions minus the number of extensions administered without hardware.


For instance: Number of extensions administered without hardware=20, Maximum number of extensions=32, Number of extensions said to be 'present'=10. The system will identify all the extensions.

For instance: Number of extensions administered without hardware=20, Maximum number of extensions=32, Number of extensions said to be 'present'=15. The system will identify the first 16 extensions said to be 'present' and ignore the last 3.

When the maximum number of extensions is reached, you may

- either remove extensions (Remove an extension, page 11-11.)
- or subscribe to a higher system capacity.

EuroGeneris menu



- Option 1:** See *Main menu*, page 3-1.
- Date and time, page 4-1.
 - System administration, page 5-1.
 - Extension administration, page 6-1.
 - Trunk administration, page 7-1.
 - Terminal translation initialization, page 8-1.
 - Routing, page 9-1.
 - Restriction, page 10-1.
 - Miscellaneous, page 11-1.
- Option 2 :** See EuroGeneris user's manual.
- Option 3 :** See EuroGeneris user's manual.



Main menu	
Date and time	1
System administration	2
Extension administration	3
Trunk administration	4
Terminal translation initialization	5
Routing Patterns	6
Data transmission	7
Restriction	8
Profiles	9
Miscellaneous	10
Select option :	..

Option 1 : See *Date and time*, page 4-1.

Option 2: See *System administration*, page 5-1.

- Power supply, page 5-2.
- S0 Bus, page 5-3.
- Number of trunks, page 5-4.
- Serial port, page 5-5.
- Serial port assignment, page 5-6.
- Feature access code, page 5-8.
- Outset of basic cabinet to extension cabinet, page 5-10.
- CT2 cordless administration, page 5-11.
- Country code, page 5-15.

Option 3: See *Extension administration*, page 6-1.

- Administer an extension, page 6-2.
- Extension group, page 6-9.
- Voice services group, page 6-11.
- Call coverage answer group, page 6-13.
- Attendant console, page 6-14.
- Call waiting indication, page 6-15.
- Access to button assignment, page 6-16.

Option 4: See *Trunk administration*, page 7-1.

- Administer a trunk, page 7-2.
- List of trunks, page 7-6.

Option 5: See *Terminal translation initialization*, page 8-1.

Option 6: See *Routing*, page 9-1.

- Incoming call distribution, page 9-2.
- Outgoing call routing, page 9-26.

Option 7: Non Accessible.

Option 8: See *Restriction*, page 10-1.

- Administer classes (COR), page 10-2.

- Administer time of day plans, page 10-5.

Option 9: Non Accessible.

Option 10: See *Miscellaneous*, page 11-1.

- Change login password, page 11-2.
- Delete system administration, page 11-3.
- Administer system wide timers, page 11-8.
- Configure VEGA DSS, page 11-9.
- Configure SOLARIS DSS, page 11-10.
- Remove an extension, page 11-11.
- Remove a trunk, page 11-12.
- Event report, page 11-13.

Date and time

Current system date:

.

Enter new date

dd-mm-yyyy-hh-mn

.....

Date and time

Used to adjust the date and time.

Enter the following in the specified order:

- day (2 char.)
- hyphen (-)
- month (2 char)
- hyphen (-)
- year (4 char)
- hyphen (-)
- hour (2 char)
- hyphen (-)
- minutes (2 char).

The day of the week (Mon-Tue-Wed-Thu-Fri-Sat-Sun) is automatically worked out by the system.

Note: The date and time are also administrable at the attendant console(s).

Note: A time setback for over 2 hours has some impact on the Call Detail Recording application and a reset of the meters is recommended.

.....

System administration	
Power supply	1
S0 bus	2
Number of trunks	3
Serial ports	4
Serial port assignment	5
Feature access code	6
Outset of basic cabinet to extension cabinet	7
CT2 Cordless administration	8
Country code	9
Select option : .	
VALIDATION	—————> Enter
PREVIOUS PAGE	—————> F4

Option 1 : See *Power supply*, page 5-2.

Option 2 : See *S0 Bus*, page 5-3.

Option 3 : See *Number of trunks*, page 5-4.

Option 4 : See *Serial port*, page 5-5.

Option 5 : See *Serial port assignment*, page 5-6.

Option 6 : See *Feature access code*, page 5-8.

Option 7 : See *Outset of basic cabinet to extension cabinet*, page 5-10.

Option 8 : See *CT2 cordless administration*, page 5-11.

- Base Identification Code, page 5-12.
- Cordless phone registration, page 5-13.
- Cordless phone deregistration, page 5-14.
- Manufacturer's parameters, page 5-14.

Option 9 : See *Country code*, page 5-15.

Power supply

Power supply

Type 1 : 100 W 1

Type 2 : 200 or 250 W 2

Type 3 : 40 W 3

Select option: .

VALIDATION ———> Enter

PREVIOUS PAGE ———> F4

Power supply

Used to define the type of power supply which is implemented.

The power supply is directly dependent on the number of terminals connected to the system.

Type	Power supply	Number of Units of Measurement
3	40 W	1 to 16 UM ^a
1	100 W	17 to 40 UM
2	250 W	41 to 104 UM

- a.
- 1 Dedicated terminal = 2 UM
 - 1 Solaris DSS = 1 Vega DSS = 4 UM
 - 1 S0 access = 2/3 UM
 - 1 Digital terminal = 1 UM.

Note: The quality of the power supply may deteriorate if the number of dedicated terminals connected to the system exceeds the capacity of the power supply which is implemented. The message "POWER OVERLOAD" will then be displayed at the attendant console(s).

Warning: Under overload conditions, the 40W power unit may trip. In that case, switch it off for a few minutes.

S0 Bus

S0 Bus

Enter port number (WXY) : 0..

W : Cabinet number

X : Slot number

Y : Jack number

Enter length option : .

- short (< 150 m) : 0

- long (> 150 m) : 1

VALIDATION -----> Enter

NEXT LINE -----> Down

PREVIOUS LINE -----> Up

PREVIOUS PAGE -----> F4

Port number
Used to select the S0 access port number for administration.

Length option
Used to define the type of bus according to the wiring implemented. See *S0 Connection*, Installation manual.

- Short bus for a «short» or «Y» wiring.
- Long bus for a «point to point» or «extended» wiring.

Number of trunks

Number of trunks

Number of trunks : ..

Number of trunks is at
the most equal to ...

VALIDATION —> Enter
 PREVIOUS PAGE —> F4

Number of trunks

Used to indicate the number of potential trunks which can be connected to the system, i.e. the number of ISDN B-channels plus the number of analog CO trunks.

Example 1: The total number of trunks is 24 when the installation includes one ISDN PRI (T2) with 20 B-channels (20 trunks) and two ISDN BRIs (T0) with 2 B-channels (4 trunks).

Example 2: The total number of trunks is 32 when the installation includes one ISDN PRI (T2) with 25 B-channels (25 trunks), two ISDN BRIs (T0) with 2 B-channels (4 trunks) and three analog CO trunks.

If the total number of the actual trunks connected to the system is less than half the declared number of potential trunks, the message «Trk non existent» is displayed at the attendant console(s).

Serial port

This option is available if the system is equipped with a serial peripheral equipment board.

The system features two serial ports.

Serial port .

Transmission speed : .
(0 = 9600 bds ; 1 = 4800 bds
2 = 2400 bds ; 3 = 1200 bds
4 = 300 bds)

Parity : .
(0 = even ; 1 = odd
2 = none)

Number of stop bits : .
(1 stop bit or 2 stop bits)

Number of bits : .
(7 bits or 8 bits)

XON-XOFF : .
(0 = inactive; 1 = active)

NEXT PORT —————> Shift Down
PREVIOUS PORT —————> Shift Up
VALIDATION —————> Enter
PREVIOUS PAGE —————> F4

Transmission speed

Used to define the throughput of the serial port. The available settings are 9600, 4800, 2400, 1200 and 300 bauds. The factory setting is 9600 bauds.

Parity

Used to define the parity. The available settings are none, even and odd. The factory setting is none.

Number of stop bits

Used to define the number of stop bits. The available settings are 1 and 2. The factory setting is 1 stop bits.

Number of bits

Used to define the word length. The available settings are 7 and 8. The factory setting is 8 bits.

Xon_Xoff

Used to define the Xon_Xoff protocol. The available settings are inactive (0) and active (1). The factory setting is inactive.

Caution for serial port configuration: Before carrying out any modifications to the standard configuration, read the peripheral equipment instructions manual.

Serial ports can accomodate:

- a printer to print the configuration report, real-time CDR reports or directory
- a modem for remote system administration (GENECOM 2 or GENECOM1)
- a PC for:
 - local system administration (GENECOM 2 or GENECOM1)
 - recovery of the real-time CDR reports via an external call detail recording (CDR) device
 - recovery of the configuration report or directory via a communications software (e.g. Terminal in Windows).

Serial port assignment is used to define only those ports used for system output (printing reports or transmitting customized CDR overload alarm - GENECOM 2). Serial port assignment is not required for system input (local or remote administration).

```

Serial port assignment
-----
Configuration reports/Real-time CDR
reports (Port A or B) .....:

Customized CDR overload alarm .....:
(Port A or B)

-----
NEXT FIELD                _____> Down
PREVIOUS FIELD            _____> Up
VALIDATION FIELD          _____> Enter
PREVIOUS PAGE             _____> F4

```

Configuration reports/Real-time CDR reports

Used to define the port used for printing the configuration report, the real-time CDR reports or the directory.

Customized CDR overload alarm

Applicable to France only.

Note: GENECOM 2 is applicable to France only.

Table 3: Configuration options

Port A	Port B	Parameters to be defined
Printer	-	Configuration report/Real-time reports
	GENECOM1	Configuration report/Real-time reports
	GENECOM2	(applicable to France only)
PC ^a	-	Configuration report/Real-time reports
	GENECOM1	Configuration report/Real-time reports
	GENECOM2	(applicable to France only)

- a. PC for:
- local system administration (GENECOM 2 or GENECOM1)
 - recovery of the real-time CDR reports via an external CDR device
 - recovery of the configuration report or the directory via a communications software (e.g. Terminal in Windows).

Table 4: Serial port priority of access

Request	Serial port status				
	Idle	Used for real-time CDR reports	Used for printing	Used with GENECOM1	Used with GENECOM2
Real-time CDR reports	Granted		Denied	Denied	Denied
Printing	Granted	Denied		Denied	Denied
Customized CDR over-load alarm	(applicable to France only)				

Note: GENECOM 2 is applicable to France only.

Feature access code

By default, extension numbers range from 300 to 399. However, the system dial plan is flexible enough to allow three or four-digit extension numbers when required (in order to match the last 3 or 4 digits of the assigned DID numbers, for instance).

Feature access code

ARS and Attendant codes (1 or 2) . :.

Option 1 : Att=9 ; ARS=0

Option 2 : Att=0 ; ARS=9

First digit

(from 1 to 8, * or #) :.

Number of digits in the

extension number (3 or 4) :.

System AD plan (0 or 1)..... :.

Option 0 : Starts at 8200

Option 1 : Starts at 8000

ARS and Attendant access codes

Used to select the ARS and attendant access codes.

First digit

Used to define the first digit needed to distinguish feature access codes from extension numbers when they are not in the form 3xx.

Thus, voice features are activated by dialing the first digit followed by the appropriate feature access codes except the following three:

- Common outgoing
- Attendant
- Internal call

Note: When a number (from 1 to 8) has been selected as first digit, extension numbers cannot begin with that number.

Number of digits

Used to define the number of digits in the extension numbers.

Note: When the system supports more than 100 extensions, the number of digits in the extension numbers is necessarily 4.

Example 1: Selected first digit: 5, Number of digits: 3

The extension numbers can range from 100 to 499 and from 600 to 899.

Example 2: Selected first digit: none, Number of digits: 4

The extension numbers range from 3000 to 3999.

Example 3: Selected first digit: 7, Number of digits: 4

The extension numbers can range from 1000 to 6999 and from 8000 to 8999.



System AD plan
Used to select AD numbers and memory access code.

Feature	Option	
	0	1
System AD	8200 to 8999	8000 to 8799
Personal AD	810 to 819	890 to 899
Memory	80	88

Note: *Selecting new AD numbers do not change the telephone numbers stored. For instance, the telephone number stored in AD number 8200 will be found in AD number 8000 and the one stored in AD number 810 will be found in AD number 890 and vice versa.*

Warning: *VEGA DSS configuration nb 2 and SOLARIS DSS configurations nb 7-9 will have to be modified manually at the respective terminals.*

Outset of basic cabinet to extension cabinet

The aim is to outset time slots of TDM bus 0 into an extension cabinet in order to use them for analog boards. (This operation is done to shift the management of all the analog boards as well as the numbering of analog ports from the basic cabinet to an extension cabinet).

Outset of basic cabinet
to extension cabinet

Validate outset (Y/N): .

Warning,
1 : Switch off the system
2 : Rearrange the boards accordingly
3 : Switch the system on again

VALIDATION ———> Enter
PREVIOUS PAGE ———> F4

This operation enables to obtain the upmost capacity for a system accommodating an ISDN PRI board. See Installation manual, *System capacity*.

Validate outset

Used to validate the outset of the basic cabinet to an extension cabinet.

Note: For administration purposes, the outset cabinet is referred to as W=3 and port numbers run from 310 to 383.

CT2 cordless administration

Note: This page is accessible if at least one base station is connected to the system..

CT2 Cordless administration

Base identification code 1

Cordless phone registration 2

Cordless phone deregistration 3

Manufacturer's parameters 4

Select option : .

VALIDATION > Enter

PREVIOUS PAGE > F4

- Option 1 :** See *Base Identification Code*, page 5-12.
- Option 2 :** See *Cordless phone registration*, page 5-13.
- Option 3 :** See *Cordless phone deregistration*, page 5-14.
- Option 4 :** See *Manufacturer's parameters*, page 5-14.

Base Identification Code

The Base IDentification code (BID) enables the system to identify cordless phones.

The BID may be modified when radio interference occurs from nearby private cordless networks (Domestic CT2 base station or CT2 PBX).

Base identification code

Current BID..... : ...

Enter new BID : ...

Included between
0401 and FFFE
(hexadecimal value).

Warning :
After modifying the BID :
1. Delete the BID on all the cordless
phones,
2. Register all the cordless phones
on the PxB.

VALIDATION > Enter

PREVIOUS PAGE > F4

Base Identification Code
Used to enter a new BID.

Note: When the BID is modified, the cordless phones have to be registered again.

Cordless phone registration

This page is used to initiate the cordless phone registration procedure.

Cordless phone registration		
List of the phones to be registered		
Ext nb	Name	Code
...
Warning :		
The above cordless phones have to be registered within the next 15 minutes.		
DISPLAY	————>	Down/Up
UPDATE	————>	Enter
PREVIOUS PAGE	————>	F4

Extension number

Cordless phone extension number. (See *Administration without hardware*, page 6-2.)

Name

Name of cordless phone user. (See *Administration without hardware*, page 6-2.)

Code

Personal code generated by the system, which must be given to cordless phone owners to enable them to carry out the registration procedure.

Note: Registered cordless phones do not appear on this page.

Registration procedure for cordless phones

1. Enter the registration sequence given in the cordless phone user's manual.
 - The programming tone can be heard and the message «Code : xxxx» may be displayed.
2. Enter the personal code which has been allocated to you.
 - If the code is correct: the programming tone can be heard and the message «Reg. ok» may be displayed.
 - If the code is incorrect, a series of 3 beeps can be heard and personal code must be reentered.

Note: After 3 unsuccessful attempts, repeat the registration procedure from the beginning.

3. Hang up.
The cordless phone is registered onto the system.



Cordless phone deregistration

When a cordless phone is deregistered from the system, it can no longer be used, but the extension administration is saved. (See *Administer an extension*, page 6-3.)

Manufacturer's parameters

Modification of these parameters is subject to the manufacturer's approval.

Country code

Country code	
Country code : .
FRANCE	: 0 BELGIUM : 1
GERMANY	: 2 THE NETHERLANDS : 3
LUXEMBOURG	: 4 SPAIN : 5
SOUTH AFRICA	: 6 UNITED KINGDOM : 7
ITALY	: 8 POLAND : 9
CZECH REP.	: 10 HUNGARY :11
SWITZERLAND	: 12 AUSTRALIA :13
Administration language	: .
FRENCH	: 0 ENGLISH : 1
GERMAN	: 2 SPANISH : 3

Country code

Used to indicate the country in which the system is installed. The system being factory-set for operation in France, it has to be hardware configured and administered for operation in each supported country.

The related parameters are initialized according to the location:

- Display language.
- Administration language.

Warning: Any attempt to modify these parameters will lead to system reinitialization.

Table 5: Parameters related to country code

Country	Display language	Administration language	Currency	Charge unit	Emergency numbers
France	French	French	Frs	1,000	17/18/15
Belgium	French	French	BEF	1,000	101/100/112
Germany	German	German	DEM	1,000	110/112
The Netherlands	Dutch	English	NLG	1,000	06-11/112/115
Luxembourg	French	French			112/113
Spain	Spanish	Spanish	PTS	7,500	091/080/061/092
South Africa	English	English	ZAR	1,000	
United Kingdom	English	English	GBP	1,000	112/999

Table 5: Parameters related to country code

Country	Display language	Administration language	Currency	Charge unit	Emergency numbers
Switzerland	French	English	CHF	1,000	117/118/144
Poland	English	English	PLZ	1,000	999/998
Czech Rep.	English	English	CSK	1,000	158/150/155
Hungary	English	English	HUF	1,000	07/05/04

Administration language

Used to define the language used for system administration.

Extension administration

Administer an extension	1
Extension group	2
Voice services group	3
Call coverage answer group	4
Attendant console	5
Call waiting indication	6
Access to button assignment	7

Select option : .

Option 1 : See *Administer an extension*, page 6-2.

- Administration without hardware, page 6-2.
- Administer an extension, page 6-3.
- Extension button assignments, page 6-7.
- Auto-answer, page 6-8.

Option 2 : See *Extension group*, page 6-9.

Option 3 : See *Voice services group*, page 6-11.

Option 4 : See *Call coverage answer group*, page 6-13.

Option 5 : See *Attendant console*, page 6-14.

Option 6 : See *Call waiting indication*, page 6-15.

Option 7 : See *Access to button assignment*, page 6-16.

Administer an extension

Extension number

Used to indicate the extension number for administration purposes.

Administration without hardware

Administration without hardware is provided to administer extensions by allowing translations to be entered before the actual ports are assigned.

```

Extension : ...

ADMINISTRATION WITHOUT HARDWARE

Terminal type .....: ..
(-----> F2)

Port number          (WXY) : ...
  W : Cabinet number
  X : Slot number
  Y : Jack number

```

Terminal type

Used to define the terminal type:

- 1 - Analog station
- 2 - Leader 48
- 3 - (Unused)
- 4 - Solaris alpha
- 5 - Véga
- 6 - Swing club
- 7 - ISDN extension
- 8 - CT2 cordless phone
- 9 - Hélios alpha
- 10 - Hélios
- 11 - Hélios ampli
- 12 - 960 alpha
- 13 - 930 alpha
- 14 - 930 or 910

Port number (WXY)

Used to indicate the port number which is made of:

- the number (W) of the cabinet housing the board:
 - 0 for basic cabinet
 - 1 for first extension cabinet
 - 2 for second extension cabinet
 - 3 for outset of basic cabinet. (See Installation manual, *System capacity*).
- the number (X) of the slot in which the board is inserted:
 - 0 to 8 for basic cabinet
 - 1 to 8 for extension cabinets
- the number (Y) of the jack where the terminal is connected:
 - 0 to 7 for Digital line boards (8PN)
 - 0 to 3 for boards supporting 4 terminals.

Administer an extension

Extension:...

User's name ... :

Auto-answer (Y/N) : .

Port number (WXY) : ...
 W : Cabinet number
 X : Slot number
 Y : Jack number

User's name

Used to identify the user of the extension.

Note: The user's name and extension number are displayed during calls.

Auto-answer

- Answer Yes if the extension is a device broadcasting pre-recorded announcement. (See *Auto-answer*, page 6-8.)
- Answer No otherwise (Factory setting is No for all terminal types except type 1).

Note: No more than 5 extensions can be declared in «Auto-answer» mode.

Extension: ...

```

COR assignment
Day class of restriction      : ..
Night class of restriction   : ..
                           (from 00 to 11)
Assign time-of-day plan (1 to 3) : .

Allow access to override night
restriction (Y/N) ..... : .
Authorization code ..... : ...

Ringing cycle for external
calls (1 to 9) ..... : .

Access to call forward off premises : .
Maximum number of simultaneous
forwarded calls (1 à 9) ..... : .

```

Day Class of restriction

Used to indicate the class of restriction assigned to the extension during the day:

- Classes 00 to 09. (See *Administer classes (COR)*, page 10-2.)
- Class 10: no restriction.
- Class 11: outgoing restriction.

Night Class of restriction

Used to indicate the class of restriction assigned to the extension at night:

- Classes 00 to 09. (See *Administer classes (COR)*, page 10-2.)
- Class 10: no restriction.
- Class 11: outgoing restriction.

Assign time-of-day plan

Used to indicate the time-of-day plan assigned to the extension. (See *Administer time of day plans*, page 10-5.)

Allow access to override night restriction

Used to enable/disable the user to override the night restriction.

Note: Factory setting is No. It is not modifiable for an S0 ISDN data terminal.

Authorization code

Used to define the 3-digit password enabling the user to override the night restriction.

Note: Non accessible for an S0 ISDN data terminal.

Used to define a ringing cycle for dedicated and digital terminals (external calls only):

- option 1: long ringing cycle (standard)
- option 2: short ringing cycle (2 beeps)
- option 3: short ringing cycle (1 beep)
- option 4: long ringing cycle
- option 5: short ringing cycle (2 short beeps)
- option 6: short ringing cycle (1 short beep)
- option 7: long ringing cycle
- option 8: short ringing cycle (2 very short beeps)
- option 9: short ringing cycle (1 very short beep).

Access to call forward off premises

Used to enable/disable the user to forward calls to an outside telephone number.

Warning: In an extension group, when the extension with the lowest number validates the call forward off-premises feature, all the incoming calls for this group will be redirected to the designated outside number.

Note: Non accessible for an S0 ISDN data terminal.

Maximum number of simultaneous forwarded calls

Used to limit the number of simultaneous calls able to be forwarded off-premises.

Note: Non accessible for an S0 ISDN data terminal.

```

Ext      : ... .
Hotline service :
Assigned destination ..... : ...
(enter extension number)
Timeout interval ..... : .. sec
(1 to 99 s)
Direct connection-Validate .. (Y/N) .
Deny access to direct connect (Y/N) .
Vega DSS configuration ..... :
(from 1 to 3)

Display language .....: .
(available display languages __> F2)

Call waiting indication .....: .
(Beep:1 ; Tone:2 ; System option:3)

```

Assigned destination

Used to indicate the extension number which is dialed automatically by the system if no dialing takes place within the predefined timeout interval.

Timeout interval

Used to define the number of seconds that must elapse before the system automatically dials the predefined extension number (assigned destination).

Note: *The timeout interval for an analog station cannot exceed:*

- 29 seconds for a system located in France
- 15 seconds for a system located in Belgium.

Direct connection-Validate

Used to enable/disable the user to directly answer incoming trunk calls.

Deny access to direct connection

Used to enable/disable the user to access the Direct connection feature at his/her terminal.

Solaris DSS configuration

Used for assigning a preprogrammed configuration to the Solaris DSS buttons. (See *Configure SOLARIS DSS*, page 11-10.)

Vega DSS configuration

Used for assigning a preprogrammed configuration to the Vega DSS buttons. (See *Configure VEGA DSS*, page 11-9.)

Display language

Used to define the display language used at the extension.

Call waiting indication

Used to indicate how the extension will be notified of a waiting call:

- Beep
- Tone
- System option. (See *Call waiting indication*, page 6-15.)

Extension button assignments

Extension: ...

A
B
C
D
E
F
G
H
I
J
K
L
M

N
O
P
Q
R
S
T
U
V
W
X
Y
Z

A:
B:
C:
D:
E:
F:
G:
H:
I:
J:
K:
L:
M:

:
:
:
:
:
:
:
:
:
:
:
:
:

:
:
:
:
:
:
:
:
:
:
:
:
:

:
:
:
:
:
:
:
:
:
:
:
:
:

HELP

→ F2

Button assignments

Used to modify the current button assignments by entering the appropriate feature access codes.

Note: On a Hélios alpha terminal, buttons 13, 25 and 26 are used for the MGO functions NEXT, PREVIOUS and VALID.

Table 6 : Available feature access codes for button assignment

Feature	Code	Feature	Code	Feature	Code
Common outgoing (ARS)	0 ^a	Alarm call	642	Direct connection	75
Return to call	1	Call appearance	643	Message retrieval	77
Toggle (Broker's call)	22	Outside transfer	644	Personal AD numbers-store	78
Trunk groups	400-409	Call pick-up	65	Place call using AD	8
Trunks	411-442	Transfer/Group park	66	Alphabetical AD	8*
Extension groups	451-458	Exclusive hold	67	Memory	80 ^a
Page an individual	460	Ringer on	68	Personal AD	81 ^a
Group page	461-468	Forward internal-activate	691	Personal AD numbers	810-819 ^a
Loudspeaker page	469	Forward off-premises-activate	695	System AD numbers	8200-8999 ^a
Voice services group	471-478	Program	7	Attendant	9 ^a
Answer incoming trunk call	5	Mute	70	Internal call	fd+Nb
Answer page	60	Drop	71		
Automatic callback	61	Leave word calling	72		
Do not disturb	62	Vega DSS-configuration	731-733		
Three-party conference	63	Solaris DSS-configuration	731-739		
Override restriction	641	Internal auto answer	74		

a. See *Feature access code*, page 5-8.

ARS: Automatic Route Selection (See *Outgoing assignments*, page 9-28.)

Auto-answer

This feature is used to connect the outside calling party to a device broadcasting pre-recorded announcements which then transfers the call. There are two auto-answer modes which are described below.

Forced first announcement.

The calling party hears the entire pre-recorded announcement before the call is transferred to the called party.

First announcement.

The calling party hears the pre-recorded announcement while the system tries to establish the connection with the called party. The caller is connected as soon as the called party answers the call.

The appropriate auto-answer mode is selected when assigning ISDN-DID numbers. (See *Assign ISDN-DID numbers*, page 9-11.)

Warning: Assign the auto-answer mode to the extension before connecting the broadcasting device.

Extension: ...

Length of pre-recorded : . sec
announcement (0 to 255 s)

Auto-answer timeout interval : . sec
(0 to 255 s)

Length of pre-recorded announcement

Used to define the length of the pre-recorded announcement.

Auto-answer timeout interval

Used to define the number of seconds that must elapse before the pre-recorded announcement is played.

Warning: The auto-answer timeout interval should exceed the DID coverage timers. (See *Coverage timers*, page 9-8.)

Hunting delay interval

Used to define the number of seconds that must elapse before DID call rings the next available extension.

Note: Useless for a Terminating extension group.

Ring several extensions at once

Used to indicate if the extension(s) previously rung will go on ringing when DID call rings the next available extension.

Extension group ..

Administered members : (up to 32)

Use Y/N to add/remove a member.

All the administered extensions appear on this screen.

Administered members

Used to indicate the group members. The administered members are shown in reverse video.

Note: An extension can only belong to one group.

Note: An S0 ISDN data extension cannot belong to a group.

Note: A group may have up to 32 members.

Voice services group

Warning: All the administered equipment must be idle while you program this option.

Voice services group number
Used to indicate the voice services group number for administration purposes.

Voice services group .

Group name :

Retrieval code :


Recording code :

Group name
Used to define the group name (12 characters).

Note: The group name and number are displayed during calls.

Retrieval code
Used to define the code to be used for playing messages.

Recording code
Used to define the code to be used for leaving messages.



```
Voice services group .  
Administered members (up to 32) :
```

All the administered analog stations appear on this screen.

Administered members

Used to indicate the group members. The administered members are shown in reverse video.

Note: *An extension can only belong to one group.*

Note: *A group may have up to 32 members.*

Attendant console

Attendant console

Attendant extension numbers : ...
and : ...

When the external ringer is active,
incoming trunk calls rings
the attendant console (Y/N) : .

Attendant extension numbers

Used to define the attendant extension numbers.

Note: When the system is switched on, the first dedicated terminal (equipped with a display) to be detected is declared as attendant console.

When the external ringer is active, incoming trunk calls ring the attendant console(s)

Used to indicate that incoming trunk calls ring the attendant console(s) when the external ringer is active. Thus, incoming trunk calls ring the attendant console(s), the external ringer and the members of the call coverage answer group at the same time.

```

Call waiting indication
-----
System call waiting indication

Beep ..... 1
Ringing tone ..... 2

Select option ..... : .
-----
VALIDATION -----> Enter
PREVIOUS PAGE -----> F4

```

Used to define the system option for call waiting indication. (See *Call waiting indication*, page 6-6.)

Access to button assignment

Access to button assignment

Deny access to extension
button assignment (Y/N)

:

.

Deny access to VEGA DSS
button assignment (Y/N)

:

.

Deny access to SOLARIS DSS
button assignment (Y/N)

:

.

- Deny access to extension button assignment

Used to enable/disable the extension user to modify the terminal button assignment.
- Deny access to VEGA DSS button assignment

Used to enable/disable the extension user to modify the VEGA DSS button assignment.
- Deny access to SOLARIS DSS button assignment

Used to enable/disable the extension user to modify the SOLARIS DSS button assignment.

Trunk administration

Administer a trunk	1
List of trunks	2

Select option : .

Option 1: See *Administer a trunk*, page 7-2.

- Administration without hardware, page 7-3.

- Administer a trunk, page 7-2.

Option 2 : See *List of trunks*, page 7-6.

Administer a trunk

Administer a trunk

Enter the port number (WXY) ...: ...

W : Cabinet number
X : Slot number
Y : Jack number

Port number (WXY)

Used to indicate the port number which is made of:

- the number (W) of the cabinet housing the board:
 - 0 for basic cabinet
 - 1 for first extension cabinet
 - 2 for second extension cabinet
 - 3 for outset of basic cabinet. (See Installation manual, *System capacity*).
- the number (X) of the slot in which the board is inserted:
 - 0 to 8 for basic cabinet
 - 1 to 8 for extension cabinets
- the number (Y) of the jack where the trunk is connected:
 - 0 to 3.
 - 0 to 3.

Note: If there are already 40 administered trunks, it is impossible to access the following pages. One trunk at least must be deleted.

Note: For an ISDN PRI trunk, the port number is WXY = 000.

Administration without hardware

Administration without hardware is provided to administer trunks by allowing line translations to be entered before the actual ports are assigned.

Administer a trunk

ADMINISTRATION WITHOUT HARDWARE

Trunk ...

Enter type of trunk : ...

RTC : Analog CO trunk

TO : ISDN-BRI

T2 : ISDN-PRI

Type of trunk

Used to define the type of trunk:

- enter «RTC» (Public Telephone Network) for an analog CO trunk
- enter «T0» for an ISDN BRI
- enter «T2» for an ISDN PRI.

ISDN-PRI Administration without hardware

```
Activate CRC (Y/N)           : .
Number of B-channels         : .
    15 B-channels (no GAL): option 0
    20 B-channels (1  GAL): option 1
    25 B-channels (2  GAL): option 2
    30 B-channels (3  GAL): option 3
```

```
Warning,
Refer to the PRI ordered from your
carrier.
```

Activate CRC

Do not modify this parameter unless you are asked to do so.

Number of B-channels

Used to indicate the number of B-channels (for ISDN PRI only).

Administer a trunk

Analog CO trunk .

Connected to a host PBX ? (Y/N) .. : .
 Enter host PBX access code : ..

Signaling mode : .
 Pulse (1) ; Tone-DTMF (0)

Trunk number : ..

Incoming only trunks appear in reverse video.
 Incoming only trunk : Y
 Outgoing or 2-way trunk : N

Connected to a host PBX

Used to indicate whether the trunk is connected to a host PBX or directly to the telephone network.

Host PBX access code

Used to define the host PBX access code (in order to respect the administered restrictions).

Signaling mode (for analog CO trunk only)

Used to indicate the signaling mode on an analog CO trunk.

Trunk number (for analog CO trunk only)

The trunk number is automatically defined by the system.

List of trunk numbers (for ISDN trunk only)

The trunk numbers are automatically defined by the system.

Note: Each number corresponds to a channel.

Type of trunk

Used to indicate if the trunk is:

- an incoming only trunk
- an outgoing or two-way trunk.

Note: With regard to ISDN trunks (T2/PRI or T0/BRI), incoming only then two-way trunks with the lowest trunk numbers are used for incoming calls.

List of trunks

This page is used to display or modify the administered trunk numbers.

List of trunks			
Trunk nb	Port nb	Trunk	type
411	080		T0
412	080		T0
413	081		T0
414	081		T0
415	082		T0
416	082		T0
417	083		T0
418	083		T0
419	050		RTC
420	051		RTC

Trunk number

Indicates the assigned trunk number.

Port number

Indicates the port number to which the trunk is connected.

Trunk type

Indicates the type of trunk.

To modify the match between trunk numbers and port numbers (*E.g. match trunk 418 to port 080*):

1. Place the cursor on the line showing the port to be newly matched (*411 ->080 RTC*)
2. Note the trunk number which appears at this position (*411*)
3. Enter the trunk number to be newly matched(*418*)
4. Move the cursor to the line showing the port which was formerly matched (*418 ->051RTC*)
5. Enter the trunk number noted in step 2 (*411*)
6. Repeat steps 1 to 5 to modify the match for another trunk or validate.

Terminal translation initialization is used:

- to match extension numbers to port numbers
- for station moves from office to office without modifying the wiring.

Note: The extension button assignment is saved.

All the administered extension numbers appear on this screen .

Extension numbers can be modified whereas port numbers can't.

Terminal translation initialization

Match port numbers with extension numbers :


300->051	317->082	330->061	398->021
301->070	318->041	331->052	399->020
302->071	319->063	332->042	->
303->072	320->080	350->083	->
304->073	322->040	360->030	->
305->060	323->043	395->010	->
314->081	324->062	396->023	->
315->050	329->053	397->022	->

To modify the match between extension numbers and port numbers (*E.g. match extension 320 to port 080*):

1. Place the cursor on the line showing the port to be newly matched (*320 080*)
2. Note the extension number which appears at this position (*320*)
3. Enter the extension number to be newly matched (*350*)
4. Move the cursor to the line showing the port which was formerly matched (*350 083*)
5. Enter the extension number noted in step 2 (*320*)
6. Repeat steps 1 to 5 to modify the match for another extension or validate.

Note: An extension number cannot be assigned to more than one port number **except** when the extension is an S0 ISDN data terminal or a cordless phone.

Note: A cordless phone extension number will be matched to the port number of the radio base station that was last used.



Routing

Incoming call distribution 1
Outgoing call routing 2

Select option : .

Option 1: See *Incoming call distribution*, page 9-2.

- Incoming trunk groups, page 9-3.
- ISDN DID, page 9-8.
- ISDN subaddressing, page 9-19.
- Coverage path Extension - Don't answer, page 9-20.
- Coverage path Extension-Active, page 9-22.
- Coverage path Extension group- Don't answer, page 9-23.
- Coverage path Extension group-Active, page 9-25.

Option 2 : See *Outgoing call routing*, page 9-26.

- Outgoing trunk groups, page 9-27.
- Outgoing assignments, page 9-28.
- ARS tables, page 9-30.
- ARS parameters, page 9-35.

Incoming call distribution

Incoming call distribution	
Incoming trunk groups	1
ISDN-DID	2
ISDN subaddressing	3
Coverage path Extension-Don't answer	4
Coverage path Extension-Active	5
Coverage path Ext gp-Don't answer ..	6
Coverage path Ext gp-Active	7
Select option :	
VALIDATION	————> Enter
PREVIOUS PAGE	————> F4

Option 1: See *Incoming trunk groups*, page 9-3.

- Day service incoming trunk group, page 9-4.
- Night service incoming trunk group, page 9-6.

Option 2 : See *ISDN DID*, page 9-8.

- ISDN-DID parameters, page 9-10.
- Assign ISDN-DID numbers, page 9-11.
- Delete ISDN-DID numbers, page 9-14.
- Display ISDN-DID numbers, page 9-15.
- Assign ISDN-DID trunks, page 9-15.
- Calling party number, page 9-16.

Option 3 : See *ISDN subaddressing*, page 9-19.

Option 4 : See *Coverage path Extension - Don't answer*, page 9-20.

Option 5 : See *Coverage path Extension-Active*, page 9-22.

Option 6 : See *Coverage path Extension group- Don't answer*, page 9-23.

Option 7 : See *Coverage path Extension group-Active*, page 9-25.

Incoming trunk groups

Up to 32 incoming trunk groups may be defined.

Incoming trunk group number

Used to indicate the trunk group number for administration purposes.

Incoming trunk group ..

Port nb	Trunk type	Group nb ..
...	..	

Use Y/N, to add/remove a member

Port number

Indicates the number of the port to which the trunk is connected.

Trunk type

Indicates the trunk type.

Group

Used to indicate whether the trunk belongs to the group.

Note: A trunk can only belong to one group.

Day service incoming trunk group

Day service incoming trunk group .

Don't answer interval (5-240s) : .. s

Assigned Voice Services group
GV. (from 1 to 8)

A trunk group can be assigned to:

- a single or several extensions
- a Voice Services group
- both extensions and Voice Services group simultaneously.

Application: When a trunk group is assigned to both the attendant console and a voice services group, the human attendant is able to pick-up the incoming call as the voice messaging system is answering it after a while. When the human attendant is unavailable or off-duty, the voice messaging system may direct the call to an automated attendant or drop it after the announcement is played.

Don't answer interval

Used to define the number of seconds that must elapse before an unanswered call is routed to the call coverage answer group.

Assigned Voice Services group

Used to define the number of the Voice Services group able to answer the incoming calls.

Day service incoming trunk group .

Assigned extensions : (up to 32)

Use Y/N to add/remove a member
VALIDATION ———> Enter

Assigned extensions

Used to define the extensions able to answer the incoming calls.

Note: Extensions belonging to the group are shown in reverse video.
An extension group may have up to 32 members.

Warning: If the extension with the lowest extension number has activated the forward off-premises or forward internal feature to a voice messaging system, the incoming call is immediately forwarded and does not ring the other extensions able to answer it.

Night service incoming trunk group

Once day service incoming trunk groups have been assigned, press Enter.

```
Night service incoming trunk group .
```

```
Don't answ. interval(5-240 s) : ..
```

```
Assigned Voices Services group  
GV. ( from 1 to 8 )
```

A trunk group can be assigned to:

- a single or several extensions
- a Voice Services group
- both extensions and Voice Services group simultaneously.

Application: When a trunk group is assigned to both the attendant console and a voice services group, the human attendant is able to pick-up the incoming call as the voice messaging system is answering it after a while. When the human attendant is unavailable or off-duty, the voice messaging system may direct the call to an automated attendant or drop it after the announcement is played.

Don't answer interval

Used to define the number of seconds that must elapse before an unanswered call is routed to the call coverage answer group.

Assigned Voice Services group

Used to define the number of the Voice Services group able to answer the incoming calls.

Night service incoming trunk group .

Assigned extensions : (up to 32)

Use Y/N to add/remove a member
VALIDATION ———> Enter

Assigned extensions

Used to define the extensions able to answer the incoming calls.

Note: Extensions belonging to the group are shown in reverse video.
An extension group may have up to 32 members.

Warning: If the extension with the lowest extension number has activated the forward off-premises or forward internal feature to a voice messaging system, the incoming call is immediately forwarded and does not ring the other extensions able to answer it.

Call termination - assigned trunks to a single or several extensions

When a call comes in on a trunk assigned to a single extension:

- the extension rings, whether it has its ringer on or not.

When a call comes in on a trunk assigned to several extensions:

- the extensions ring only if they have their ringer on. Otherwise, the call is directed to the call coverage answer group.

If unanswered during the assigned don't answer interval, the call is directed to:

- the attendant console(s)
- the administered members of the coverage answer group having their ringer on
- the external ringing unit if the attendant consoles have their ringer off.

Call termination - non assigned trunks

The incoming call rings:

- the attendant console(s) having their ringer on or not
- the administered members of the coverage answer group having their ringer on
- the external ringing unit if the attendant console(s) have their ringer off.

ISDN DID

ISDN-DID	
ISDN-DID parameters	1
Assign ISDN-DID numbers	2
Delete ISDN-DID numbers	3
Display ISDN-DID numbers	4
Assign ISDN-DID trunks	5
Calling party number	6
Select option :	.

- Option 1:** See *ISDN-DID parameters*, page 9-10.
- Option 2 :** See *Assign ISDN-DID numbers*, page 9-11.
- Option 3 :** See *Delete ISDN-DID numbers*, page 9-14.
- Option 4 :** See *Display ISDN-DID numbers*, page 9-15.
- Option 5 :** See *Assign ISDN-DID trunks*, page 9-15.
- Option 6 :** See *Calling party number*, page 9-16.
- Add/Modify Extension nb-Calling party nb, page 9-17.
 - Delete Extension nb - Calling party nb, page 9-17.
 - Display Ext nb - Calling party nb, page 9-17.
 - Automatic CPN assignment, page 9-17.
 - Area code, page 9-18.



The various DID call processing modes

DID number analysis depends on the public network to which the system is connected.

The various parameters taken into account for DID call processing are:

- DID number lengths
- DID number contents:
 - extension number only
 - full number
- DID number reception mode:
 - in block (Number with ending delimiter)
 - overlapping (Number with or without ending delimiter)

Table 7 : DID call processing mode - classification by country

<i>Reception mode</i>	<i>DID number contents</i>	
	<i>Full number</i>	<i>Extension number only</i>
Block	The Netherlands, Belgium, Germany, Luxembourg	France, United Kingdom
Overlapping	Germany, Luxembourg	Germany, Luxembourg

ISDN-DID parameters

ISDN DID Parameters	
Parameters of DID numbers :	
Number of significant digits	:
Number of non-significant digits	:
Interdigit timer	: .. s
DID coverage timeout intervals (5 to 240s)	
Don't answer interval - Ext ...	: .. s
Busy interval - Ext	: .. s
Attendant interval	: .. s
Don't answer interval - Ext Grp	: .. s
Busy interval - Ext Grp	: .. s
VALIDATION —————> Enter	
PREVIOUS PAGE —————> F4	

Number of significant digits

Used to define the maximum number of digits in the DID number which will be taken into account for DID call routing.

Warning: This parameter must be assigned a value.

Number of non-significant digits

Used to define the number of digits in the DID number which will not be taken into account for DID call routing.

Warning: This parameter must be assigned a value when DID number reception mode is 'overlapping' and DID number contents is 'full number'.

Interdigit timer

Used to define the number of seconds that must elapse before a DID number in overlapping reception mode without ending limiter, is regarded as complete by the system.

DID coverage timeout intervals

Used to define the number of seconds that must elapse before a DID call is redirected to another extension, extension group, Voice Services group or attendant console. (See page 20 to page 25)

DID coverage timeout intervals are:

- don't answer interval-extension
- busy interval-extension
- attendant interval
- don't answer interval-ext. group
- busy interval-ext. group.

Assign ISDN-DID numbers

DID numbers are assigned in lists of up to 10 consecutive numbers. The system supports up to 100 DID numbers.

Assign ISDN-DID numbers

First DID number in list:

Number in consecutive DID numbers

In the list : ..

(Up to 10)

VALIDATION

NEXT LINE

PREVIOUS LINE

PREVIOUS PAGE

————> Enter

————> Down

————> Up

————> F4

First DID number in list

Used to define the first DID number in the list.

In some countries DID numbers vary in length.

Example: 9 digits «069 95321 0» for the attendant DID number and 12 digits «069 95321 4001» for an extension within the same PBX.

In this example, the number of significant digits is 4 and the number of non-significant digits is 8.

In this case, at least 2 lists must be created:

- one beginning with «0» for 9-digit numbers
- one beginning with «069 95321 4001» for 12-digit numbers.

Number of consecutive DID numbers

Used to define the number of DID numbers in the list.

Note: A list of DID numbers cannot contain more than10 numbers.

Assign ISDN-DID numbers				
DID nb	Ext nb	Auto Answ	Tod Mode	Additional Plan info.
ToD :According to time-of-day plan (Y/N) Mode:First announcement (0) Forced first announcement (1)				
VALIDATION			————>	Enter
PREVIOUS PAGE			————>	F4

DID number

Indicates the DID number.

Extension number

Used to assign the DID number to an extension, an extension group, the attendant console or a Voice Services group. To assign a DID number:

- to an extension:
 - Enter the extension number.

Note: To make sure that DID extension numbers (M)CDU match extension numbers, first administer the section «Feature access code, page 5-8.», then modify the extension numbers in the section «Terminal translation initialization, page 8-1.». An extension can be assigned to several DID numbers.

- to an extension group:
 - Enter G followed by the group number (from 1 to 8).

Warning: If the extension with the lowest extension number has activated the forward off-premises or forward internal feature to a voice messaging system, the incoming call is immediately forwarded and does not ring the other extensions able to answer it.

- to the attendant console:
 - Enter «PO».
- to a Voice Services group:
 - Enter GV followed by the Voice Services group number (from 1 to 8).

Auto-answer

Used to define the 'auto-answer' extension number the calling party will be connected to. Leave blank if you do not wish to validate the auto-answer feature.

Note: You must enter an 'auto-answer' extension number.



Mode

Used to define the auto-answer mode. (See *Auto-answer*, page 6-8.)

- 0 : First announcement
- 1 : Forced first announcement.

Time-of-day plan

Used to define whether the auto-answer feature is active at all times or according to the time-of-day plan assigned to the extension.

- Answer Yes to activate the auto-answer feature according to the time-of-day plan assigned to the extension.
- Answer No to activate the auto-answer feature at all times.

Note: When the night service is activated at the attendant console, the auto-answer feature is deactivated.

Additional information

Used to define the additional information (8 characters) to be displayed on terminals on call arrival.

Note: By default the last 4 digits of the DID number are added to the additional information.

Delete ISDN-DID numbers

Delete ISDN-DID numbers

First DID number in list:
Number in consecutive DID number
in the list : ..
(up to 10)

VALIDATION ———> Enter
NEXT LINE ———> Down
PREVIOUS LINE ———> Up
PREVIOUS PAGE ———> F4

First DID number in list
Used to define the first DID number in the list to be deleted.

Number of consecutive numbers in the list
Used to define the number of DID numbers in the list to be deleted.

Note: A list of DID numbers cannot contain more than 10 numbers.


Delete ISDN-DID numbers

DID	Ext	Auto	Tod	Additional
nb	nb	Answ	Mode	Plan info.

Warning, if you press ENTER
the displayed numbers are deleted.

DELETE ———> Enter
PREVIOUS PAGE ———> F4

This screen is used to confirm the deletion of DID numbers.



Display ISDN-DID numbers

This screen is used to display DID numbers.

Assign ISDN-DID trunks

Assign ISDN-DID trunks

Port nb	Trunk type	ISDN DID
...	..	

VALIDATION

ADD A TRUNK

REMOVE A TRUNK

PREVIOUS PAGE

————>

Enter

————>

Enter Y

————>

Enter N

————>

F4

All the administered ISDN PRI and BRI trunks are displayed.

Port number

Indicates the port number to which the trunk is connected.

Trunk type

Indicates the trunk type.

ISDN DID

Used to define whether the trunk is to support DID.

Note: On start-up, there are no trunks supporting DID.

Calling party number

Calling party numbers enable extension users to be identified by the called party. The system is set to send the DID numbers assigned to the extensions.

However, an extension user may:

- be identified by a DID number other than that assigned (e.g. the attendant DID number)
- be identified by a DID number even if none has been assigned to the extension
- not be identified by a DID number.

Calling party number

Add/Modify Ext nb-Calling party nb ..1
Delete Ext nb-Calling party nb2
Display Ext nb-Calling party nb3
Automatic CPN assignments4
Area Code5

Select option : .

VALIDATION

————> Enter

PREVIOUS PAGE

————> F4

- Option 1:** See *Add/Modify Extension nb-Calling party nb*, page 9-17.
- Option 2 :** See *Delete Extension nb - Calling party nb*, page 9-17.
- Option 3 :** See *Display Ext nb - Calling party nb*, page 9-17.
- Option 4 :** See *Automatic CPN assignment*, page 9-17.
- Option 5 :** See *Area code*, page 9-18.

Add/Modify Extension nb-Calling party nb

Add/Modify Extension nb-Calling party nb

Ext number: ..

CPN number : ..

Extension number

Used to select an extension to administer the calling party number (CPN).

Note: CPN administration is always done extension by extension.

CPN number

Used to define the calling party number.

Note: The system does not monitor the contents of this field and the information it contains is the sole responsibility of the administrator.

Warning: An S0 ISDN terminal equipment must send its extension number to the S Bus to allow the system to send the assigned CPN number to the public network..

Delete Extension nb - Calling party nb

Used to delete a calling party number.

Display Ext nb - Calling party nb

Used to display the list of the calling party numbers that are assigned to extensions.

Automatic CPN assignment

Used to automatically copy assigned DID numbers in the «CPN number» field.
(See *Display ISDN-DID numbers*, page 9-15.)

Note: All prior configurations are deleted.

Note: Extension groups, Voice Services groups, extensions declared in "auto-answer" mode- and attendant console(s) are not taken into account in the automatic CPN assignment procedure.

Area code

Area code

Area code :


Area code

Used to select an extension to administer the calling party number (CPN).

Table 8 : Area code

	Country				
	France except DOM	French DOM	Germany The Netherlands	Belgium	Switzerland United Kingdom
Number dialed inside the area	0ZABPQMCDU	0ZABPQMCDU or PQMCDU	0 + Area code + n digits or n digits	n digits	0 + Area code + n digits or n digits
Number dialed outside the area	0ZABPQMCDU	0ZABPQMCDU	0 + Area code + n digits	0 + Area code + n digits	0 + Area code + n digits
Number sent by the network	ZABPQMCDU	ZABPQMCDU	Area code + n digits	Area code + n digits	0 + Area code + n digits
Code to be entered	None	ZAB	Area code	Area code	0 + Area code

ISDN subaddressing




ISDN-subaddressing coverage timers

Used to define the the number of seconds that must elapse before an ISDN call with a subaddress is redirected to another extension, extension group, Voice Services group or attendant console. (See page 20 to page 25)

The ISDN-subaddressing coverage timers are:

- don't answer interval
- busy interval
- attendant interval.



Extension numbers

Used to assign subaddresses to extensions.

Note: Extensions which are assigned a subaddress appear in reverse video.

Coverage path Extension - Don't answer

Redirection takes place if the principal does not answer the call within the don't answer interval (See *ISDN-DID parameters*, page 9-10. or See *ISDN subaddressing*, page 9-19.).

Coverage path Extension-Don't answer

Enter extension number : ...

Extension number

Used to select an extension number for administration purposes.

Coverage path Extension-Don't answer

```

Extension number ..... : ...
User's name ..... : .....

Coverage point ..... : .
- Attendant (1)
- Extension (2)
- Extension group (3)
- Voice Services group (4)

Answering position ..... : ...
- Extension
- Extension group ( G1 to G8 )
- Voice Services group ( GV1 to GV8 )
  
```

Extension number

Indicates the selected extension number.

User's name

Indicates the extension user's name.

Coverage point

Used to select the type of coverage.

Answering position

Used to define the covering user:

- If option 1 was selected, the letters «PO» are automatically displayed.
- If option 2 was selected:
 - Enter the extension number.
- If option 3 was selected:
 - Enter the extension group number (G1 to G8).
- If option 4 was selected:
 - Enter the Voice Services group number (GV1 to GV8).

Coverage path Extension-Active

Redirection takes place if the principal is active and not able to answer the call within the busy interval (See *ISDN-DID parameters*, page 9-10. or See *ISDN subaddressing*, page 9-19.).

Coverage path Extension-Active

```

Extension number..... : ...
User's name ..... : .....

Type of redirection ..... : .
- Immediate (1)
- Delayed (2)
- Drop (3)

Coverage point ..... : .
- Attendant (1)
- Extension (2)
- Extension group (3)
- Voice services group (4)

Answering position ..... : ...
- Extension
- Extension group ( G1 to G8 )
- Voice services group (GV1 to GV8)

```

For the «Extension number», «User's name», «Coverage point» and «Answering position» parameters, See *Coverage path Extension - Don't answer*, page 9-20.

Type of redirection

Used to select the type of redirection:

- Select option 1 to route the calls immediately to the covering user.
- Select option 2 to ring the principal during the busy interval and route the calls to the covering user on timeout.
- Select option 3 to inhibit redirection and drop the calls.

Coverage path Extension group- Don't answer

Redirection takes place if the principal does not answer the call within the don't answer interval (See *ISDN-DID parameters*, page 9-10. or See *ISDN subaddressing*, page 9-19.).

Coverage path Ext gp-

Enter extension group number ...: G.

VALIDATION
————> Enter

PREVIOUS PAGE
————> F4

Extension group number

Used to select an extension group number for administration purposes.

Coverage path Ext gp-Don't answer

```

Group number ..... : G.
Name of group ..... : .....

Coverage point ..... : .
- Attendant          (1)
- Extension           (2)
- Extension group     (3)
- Voice services group (4)

Answering position ..... : ...
- Extension
- Extension group     ( G1 to G8 )
- Voice services group ( GV1 to GV8 )

```

Group number

Indicates the selected group number.

Name of group

Indicates the name of the group.

Coverage point

Used to select the type of coverage.

Answering position

Used to define the covering user:

- If option 1 was selected, the letters «PO» are automatically displayed.
- If option 2 was selected:
 - Enter the extension number.
- If option 3 was selected:
 - Enter the extension group number (G1 to G8).
- If option 4 was selected:
 - Enter the Voice Services group number (GV1 to GV8).

Coverage path Extension group-Active

Redirection takes place if the principal is active and not able to answer the call within the busy interval (See *ISDN-DID parameters*, page 9-10. or See *ISDN subaddressing*, page 9-19.).

Coverage path Ext gp-Active

Group number : G.

Name of group :

Type of redirection : .

- Immediate (1)
- Delayed (2)
- Drop (3)

Coverage point : .

- Attendant (1)
- Extension (2)
- Extension group (3)
- Voice services group (4)

Answering position : ...

- Extension
- Extension group (G1 to G8)
- Voice services group (GV1 to GV8)

For the «Group number», «Name of group», «Coverage point» and «Answering position» parameters, See *Coverage path Extension - Don't answer*, page 9-20.

Type of redirection

Used to select the type of redirection:

- Select option 1 to route the calls immediately to the covering user.
- Select option 2 to ring the principal during the busy interval and route the calls to the covering user on timeout.
- Select option 3 to inhibit redirection and drop the calls.

Outgoing call routing

Outgoing call routing

Outgoing trunk groups 1

Outgoing assignments 2

ARS tables 3

ARS parameters 4

Select option : .

- Option 1:** See *Outgoing trunk groups*, page 9-27.
- Option 2 :** See *Outgoing assignments*, page 9-28.
- Option 3 :** See *ARS tables*, page 9-30.
- ARS time-of-day charts, page 9-31.
 - ARS digit analysis tables, page 9-33.
 - ARS route pattern tables, page 9-34.
- Option 4 :** See *ARS parameters*, page 9-35.

Outgoing trunk groups

Up to 10 outgoing trunk groups may be defined.

Trunk group 4.

Administered members :

...

...

...

...

...

...

...

...

...

...

Use Y/N, to add/remove a member

All the administered trunks appear on this screen.

Administered members

Used to indicate the administered members. Trunks belonging to the group are displayed in reverse video.

Warning: Incoming only trunks should not belong to an outgoing trunk group.

Note: On start-up, all the trunks belong to trunk group 400.

Note: With regard to ISDN trunks (T2/PRI or T0/BRI), incoming only then two-way trunks with the lowest trunk numbers are used for incoming calls.

Note: A trunk may belong to several groups.

Outgoing assignments

Outgoing assignments

Enter extension number : ...

Outgoing assignments are administered extension by extension.

Outgoing assignment for extension ...

Enter trunk or trunk group numbers
in order of priority

common access	selective access
1 - ..	1 - ..
2 - ..	2 - ..
3 - ..	3 - ..
4 - ..	4 - ..
5 - ..	5 - ..
6 - ..	6 - ..
7 - ..	7 - ..
8 - ..	8 - ..
9 - ..	9 - ..
10 - ..	10 - ..

Common access

Used to assign the trunks (410 to 449) or trunk groups (400 to 409) to the selected extension in common outgoing access and define their order of priority. Outgoing trunks or trunk groups in common access can normally be seized by dialing the feature access code 0 which activates the ARS feature.

Note: Analog CO trunks are seized before ISDN trunks.

Note: On start-up, all the extensions have access to trunk group 400.

Selective access

Used to assign the trunks (410 to 449) or trunk groups (400 to 409) to the selected extension in selective outgoing access. Outgoing trunks or trunk groups in selective access can be seized by dialing the feature access codes 400 to 409 and 410 to 449.

Note: If the extension is a data terminal, the «selective access» option is non accessible.

Automatic route selection (ARS)

ARS routes calls over the public network based on the preferred (normally the least expensive) route available at the time the call is placed.

Definitions

Common access

ARS begins when the user dials the common access or ARS access code (normally the digit 0).

Note: Selective access does not activate the ARS feature.

Time-of-day chart

Allows the system to select a digit analysis table according to the day and time the call is placed.

Digit analysis table

Allows the system to select a route pattern table according to the number dialed.

Route pattern table

Allows the system to:

- Select the trunk group to be used according to trunk availability.
- Delete or insert digits in the dialed number according to the trunk group that is to be used.

Behaviour

1. When the user dials the ARS access code (normally the digit 0), the system selects a digit analysis table according to the day and time the call is placed.
2. The system compares the dialed number with entries in the ARS digit analysis table. When the system finds a dialed string entry in the table that matches the dialed number, the ARS digit analysis table maps the dialed number to a specific route pattern table. When there is no mapping, a default route pattern table is selected.
3. In the route pattern table, the system selects the preferred trunk group that can be used for the call among the available ones (a trunk group is available if at least one trunk in the group is available).
4. According to the trunk group that will be used, the system deals with the necessary digit manipulations (digit deletion & insertion in the dialed number) then routes the call.

ARS tables

ARS tables

ARS time-of-day charts 1

ARS digit analysis tables 2

ARS route pattern tables 3

Select option : .

- Option 1:** See *ARS time-of-day charts*, page 9-31.
- Option 2 :** See *ARS digit analysis tables*, page 9-33.
- Option 3 :** See *ARS route pattern tables*, page 9-34.

ARS time-of-day charts

ARS time-of-day charts

Monday	1
Tuesday	2
Wednesday	3
Thursday	4
Friday	5
Saturday	6
Sunday	7

Select option : .

ARS time-of-day charts are administered on a week basis.

ARS time-of-day chart :

.....

Digit analysis table	
nb . is active sinceh..
Activation Digit analysis	
Time table (1 - .)	
..h..	.
..h..	.
..h..	.
..h..	.
..h..	.
..h..	.
..h..	.
..h..	.
..h..	.
..h..	.
..h..	.

Each day may be divided in up to 12 time-segments. A time-segment is defined by indicating the opening time. A segment opening automatically defines the end of the previous one.

Example: A segment opening at 14h00 automatically defines the end of the previous segment at 13H59.

Digit analysis table nb x is active since

Gives information on the active digit analysis table:

- Table number.
- Segment opening (day and time).

Activation time

Used to indicate the segment opening time.

Digit analysis table

Used to indicate the digit analysis table used during the specified segment.

ARS digit analysis tables

Up to 6 ARS digit analysis tables may be defined.

ARS digit analysis table	..
<p>If the dialed number doesn't belong to the digit analysis table,</p> <p>the route pattern table is :</p> <p>(1-..)</p> <p>with a minimum equal to : ..</p> <p>and a maximum equal to : ..</p>	

Used to define the default route pattern table that will be used when there is no mapping between the dialed number and the table entries.

ARS digit analysis table		..
Dialed number	Route pattern table (1-..)	Min Max
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

An ARS digit analysis table may contain up to 30 entries.

Dialed number

Used to define the table entries.

Route pattern table

Used to indicate the number of the route pattern table to be used.

Minimum

Used to define the minimum number of digits to be dialed to place a call.

- Dialing is regarded as complete as soon as the minimum number of digits has been reached.
- Dialing is regarded as incomplete as long as the minimum number of digits has not been reached .

Maximum

Used to define the maximum number of digits to be dialed to place a call.

- Dialing is regarded as complete as soon as the maximum number of digits has been reached.

ARS route pattern tables

Up to 15 ARS route pattern tables may be defined.

ARS route pattern table ..

TG	DEL	INS	CPN	COM
.
.
.
.
.

TG : Trunk group
DEL: Nb of digits to be deleted
INS: Inserted digits
CPN: 0->none; 1-> DID nb; 2->Ext nb
COM: Comments

An ARS route pattern table may contain up to 5 entries. Entries are entered in order of preference.

Trunk group

Used to define the trunk group to be used.

Number of digits to be deleted

Used to indicate the number of digits to be deleted in the number which has been dialed.

Inserted digits

Used to indicate the digits/characters to be inserted in the number which has been dialed. They may be:

- Digits from 0 to 9 or characters such as “*” or “#”.
- “-” to insert a pause with administrable length. See *ARS parameters*, page 9-35.

- EuroGeneris administration manual 9-35

Short inter-digit timer

Used to define the number of seconds that must elapse between each digit dialed.

- This timer is active as long as the minimum number of digits has not been reached. See *ARS digit analysis tables*, page 9-33.
- Dialing is regarded as incomplete when this timer expires, and the calling party receives the busy tone.

Long inter-digit timer

Used to define the number of seconds that must elapse between each digit dialed.

- This timer is active as soon as the minimum number of digits has been reached. See *ARS digit analysis tables*, page 9-33.
- Dialing is regarded as complete when this timer expires or when the maximum number of digits is reached.

Tone detection

Used to define the number of seconds that must elapse before the network sends dial tone. If no dial tone is received when the timer expires, the system goes on with the dialing process.

Select option for a digit indicating the end of dialing

Used to define the digit(s) which let the system know that dialing is complete. To override the timer for faster call processing, the calling party may dial this digit to indicate end of dialing.

Restriction

Administer classes (COR) 1
Administer time-of-day plans 2

Select option : .

Option 1: See *Administer classes (COR)*, page 10-2.

- Emergency call list, page 10-2.

- Classes of restriction (CORs), page 10-3.

Option 2 : See *Administer time of day plans*, page 10-5.

Administer classes (COR)

```

Administer classes (COR)
-----
-
Enter class number ..... : ..
or,
enter "E",
to display the emergency call list

12 classes are available

Each extension is assigned a COR :
- restricted call lists (from 0 to 9)
- no restriction      (10)
- outward restriction  (11)
-----
-
VALIDATION                -----> Enter

```

Emergency call list

[illegible]

Emergency number

Used to administer up to ten 4-digit emergency numbers.

Operating hints:

To enable an extension to access to the emergency call list, it must be assigned an administrable COR which contains at least one emergency number in its unrestricted call list.

Classes of restriction (CORs)

Up to twelve classes of restriction are available. Two of them are preset and the other ten are administrable:

- from 0 to 9: restricted call lists
- 10: no restriction
- 11: outward restriction.

Administering a class

[illegible]

Restricted

Used to deny the access to up to fifteen 6-digit area codes.

Unrestricted

Used to allow the access to up to fifteen 6-digit area codes.

Operating hints:

CORs may be administered in three different ways:

- Restriction without exception
- Restriction with exceptions
- Unrestriction

Restriction without exception:

Use the restricted call list to deny the access to some areas.

For instance: Deny international calls.

Restriction with exceptions:

Use both lists to allow for exceptions.

For instance: Deny international calls but allow calls to a specific country.

Unrestriction:

Use the unrestricted call list to allow the access to some areas.

For instance: Allow local calls.

Administer time of day plans

Extensions may be assigned a different COR according to day (working hours) and night (non working-hours).

Night/Day restriction is activated:

- manually by dialing the appropriate feature access code at the attendant console
- automatically according to one of the three time-of-day plans.

An extension is assigned (See *Administer an extension*, page 6-3.) :

- a day COR
- a night COR
- a time-of-day plan.

The 3 time-of-day plans are used to define when the night restriction will be activated.

Restriction . time-of-day plan

Enter day schedule :

	start	stop	start	stop
MONDAY	: 07:00	12:30	13:00	19:00
TUESDAY	: 07:00	12:30	13:00	19:00
WEDNES.	: 07:00	12:30	13:00	19:00
THURSDAY	: 07:00	12:30	13:00	19:00
FRIDAY	: 07:00	12:30	13:00	19:00
SATURDAY	: 07:00	12:30	13:00	19:00
SUNDAY	: 07:00	12:30	13:00	19:00

NEXT LINE

PREVIOUS LINE

————>

Shift Down

Shift Up

Note: The time-of-day plans are initially pre-programmed as follows:

- Time-of-day plan 1: from 07.00 to 12.00 and from 12.00 to 19.00
- Time-of-day plan 2: from 07.00 to 12.30 and from 13.00 to 19.00
- Time-of-day plan 3: from 08.00 to 12.00 and from 14.00 to 18.00

Start

Used to define when day restriction is activated.

Stop

Used to define when day restriction is deactivated.

Table 9 : Example of a time-of-day plan with two non-working days

	<i>Start</i>	<i>Stop</i>	<i>Start</i>	<i>Stop</i>
Monday	08:00	12:00	14:00	18:00
Tuesday	08:00	12:00	14:00	18:00
Wednesday	08:00	12:00	14:00	18:00
Thursday	08:00	12:00	14:00	18:00
Friday	08:00	12:00	14:00	18:00
Saturday
Sunday

Miscellaneous

Miscellaneous

Change login password	1
Delete system administration	2
Administer timers	3
Configure VEGA DSS	4
Configure SOLARIS DSS	5
Remove an extension	6
Remove a trunk	7
Event report	8

Select option : .

Option 1: See *Change login password*, page 11-2.

Option 2 : See *Delete system administration*, page 11-3.

- Delete all personal AD numbers, page 11-4.
- Delete all the outgoing assignments, page 11-4.
- Delete all the extension assignments, page 11-5.
- Delete all the trunk assignments, page 11-6.
- Delete a trunk group, page 11-6.
- Re-initialize an extension, page 11-7.
- Re-initialize the system, page 11-7.

Option 3 : See *Administer system wide timers*, page 11-8.

Option 4 : See *Configure VEGA DSS*, page 11-9.

Option 5 : See *Configure SOLARIS DSS*, page 11-10.

Option 6 : See *Remove an extension*, page 11-11.

Option 7 : See *Remove a trunk*, page 11-12.

Option 8 : See *Event report*, page 11-13.

- Event report criteria, page 11-14.
- Real-time event report, page 11-15.
- Event report scheduled output, page 11-16.

Change login password

1. Enter your current login password.
2. Enter your new login password.

Change login password

—

Current login password ...: .

—

VALIDATION ———> Enter

PREVIOUS PAGE ———> F4

3. Re-enter your new login password to confirm and then validate.

After changing the login password, only the new password will be valid for the next connection to the minitel local server.

To change the end-user's login password «E», follow the same procedure.

Warning: Remember to keep this new password in a safe place. Should you lose or misplace it, you will no longer be able to administer your system and will, therefore, have to re-initialize it.

.....

```

Delete system administration

```

```

Delete all personal AD numbers ... 1
Delete all outgoing assignments .. 2
Delete all extension assignments . 3
Delete all trunk assignments ..... 4
Delete a trunk group ..... 5
Re-initialize an extension ..... 6
Re-initialize the system ..... 7

```

Select option : .

Option 1: See *Delete all personal AD numbers*, page 11-4.

Option 2 : See *Delete all the outgoing assignments*, page 11-4.

Option 3 : See *Delete all the extension assignments*, page 11-5.

Option 4 : See *Delete all the trunk assignments*, page 11-6.

Option 5 : See *Remove a trunk*, page 11-12.

Option 6 : See *Re-initialize an extension*, page 11-7.

Option 7 : See *Re-initialize the system*, page 11-7.

Delete all personal AD numbers

```
Delete all personal AD numbers

-

Do you want to delete all AD numbers ?
(Y/N) : .

-

VALIDATION          -> Enter
PREVIOUS PAGE       -> F4
```

Delete all personal AD numbers

Used to delete the personal AD numbers for all the dedicated terminals.

Delete all the outgoing assignments

```
Delete all the outgoing routing patterns

-

Do you want to delete outgoing
destinations for :

- all the ISDN extensions ..... 1
- all the telephone extensions . 2
- all the extensions ..... 3

Select option : .
```

Delete all the outgoing assignments

Used to delete the following outgoing assignments:

1. S0 ISDN data extensions only
2. telephone extensions only
3. all the extensions (both S0 ISDN data and telephone extensions).

Delete all the extension assignments

```

Delete all the extension assignments
-----
Do you want to delete the assignments
for :
- all the telephone extensions ... 1
- all the ISDN extensions ..... 2
- all the extensions ..... 3

Select option: .

```

Delete all the extension assignments

Used to delete the following extension assignments:

1. telephone extensions only
2. S0 ISDN data extensions only
3. all the extensions (both S0 ISDN data and telephone extensions).

Note: This operation applies to idle extensions only.

Note: When this operation is completed, extension administration returns to the original «factory-set» configuration.

Delete all the trunk assignments

```

Delete all the trunk assignments
-----
Do you want to delete the assignments
for :
- all analog CO trunks ..... 1
- all ISDN-BRIs ..... 2
- all ISDN-PRIs ..... 3

Select option : .
  
```

Delete all trunk assignments

Used to delete the following trunk assignments:

1. analog CO trunks
2. ISDN-BRIs (T0)
3. ISDN-PRIs (T2)

Delete a trunk group

```

Delete a trunk group
-----
-

Enter group number : ..

-----
-
VALIDATION           -> Enter
PREVIOUS PAGE       -> F4
  
```

Delete a trunk group

Used to delete a trunk group assignment.

Note: Trunk group numbers are included between 01 and 16.

Re-initialize an extension

```

Re-initialize extension ...

Delete button assignment ..... 1
Delete outgoing routing pattern .... 2
Delete all extension assignments ... 3

Select option : .

```

Re-initialize extension

Used to delete the following extension assignments:

1. button assignments only
2. outgoing routing pattern only
3. all extension assignments.

Re-initialize the system

```

Re-initialize the system

Delete system configuration
and restart the system ..... 1
Restart the system only ..... 2

Select option : .

VALIDATION      -> Enter

```

Re-initialize the system

1. Used to delete the entire system configuration except the alphabetical AD.
2. Used to restart the system only.

Administer system wide timers

Administer system wide timers

```
Flashhook interval (in ms)
  lower bound ( 50 ms ) ..... : ... ms
  upper bound ( 900 ms ) ..... : ... ms
Host PBX-Flash length (in ms) : ... ms

Call forward timer value .... : .. s
( 1 to 40 s )
Intrusion timer value ..... : .. s
( 1 to 30 s )
Exclusive hold timer value ... :... s
(20 to 240 s)
Call park timer value ..... : ... s
(20 to 240 s)
Call transfer timer value .... : .. s
(20 to 40 s)
```

Flashhook interval

Used to define the lower and upper bounds of the flash duration accepted by the system (recall signaling) and transmitted by a touch-tone dialing analog station before dialing a feature code.

Note : The flashhook interval transmitted by an analog station can vary from model to model.

Host PBX-Flash length

Used to define the length of the flash signal (recall signaling) to be generated by the system toward the network (Central Office). This value is included between 90 and 999 ms.

Call forward timer value

Used to define the number of seconds that must elapse before a forwarded call, remaining unanswered, returns to the requested extension.

Intrusion timer value

Used to define the time an intrusion may last.

Exclusive hold timer value

Used to define the time a call may stay on hold when an exclusive hold is carried out.

Call park timer value

Used to define the time a call may stay on hold when a call park is carried out.

Call transfer timer value

Used to define the number of seconds that must elapse before a transferred call, remaining unanswered, rings the call coverage answer group and the attendant console(s).

Configure VEGA DSS

The system supports up to three VEGA terminals equipped with DSS. Three basic VEGA DSS configurations are available.

Configuration . Vega DSS

1 : : ...

2 : : ...

3 : : ...

4 : : ...

5 : : ...

6 : : ...

7 : : ...

8 : : ...

9 : : ...

10 : : ...

11 : : ...

12 : : ...

13 : : ...

14 : : ...

15 : : ...

16 : : ...

Extension with this DSS configuration

.

HELP —> F2

p 1/4

Note: VEGA DSS configurations cannot be modified by minitel. They may only be modified at a terminal equipped with a DSS.

- To display the next 16 buttons, press Enter
- To display the previous 16 buttons, press F4

Table 10 : VEGA DSS configuration table

Configuration number	Extensions		Trunks		AD numbers	
	Quantity	Number	Quantity	Number	Quantity	Number
1	48	300 to 347	16	410 to 425	0	-
2	0	-	0	-	64	8200 to 8263
3	54	300 to 353	10 call appearances			

Configure SOLARIS DSS

The system supports up to nine SOLARIS terminals equipped with DSS. Nine basic Solaris DSS configurations are available.

```

Configuration . Solaris DSS
----- p 2/6

. 1 . 13 | 13 :           : ...
. 2 . 14 | 14 :           : ...
. 3 . 15 | 15 :           : ...
. 4 . 16 | 16 :           : ...
. 5 . 17 | 17 :           : ...
. 6 . 18 | 18 :           : ...
. 7 . 19 | 19 :           : ...
. 8 . 20 | 20 :           : ...
. 9 . 21 | 21 :           : ...
.10 . 22 | 22 :           : ...
.11 . 23 | 23 :           : ...
.12 . 24 | 24 :           : ...

Extension with this DSS configuration :
.
.
HELP                               -----> F2

```

- To display the next 12 buttons, press Enter.
- To display the previous 12 buttons without validating the current configuration, press F4.
- To display the next line, press Down.
- To display the previous line, press Up.

Table 11 : Solaris DSS configuration table

Configuration number		Extensions		Trunks		AD numbers	
		Quantity	Number	Quantity	Number	Quantity	Number
1-2	Sol. DSS 1	8	300 to 307	16	410 to 4256	0	-
	Sol. DSS 2	24	308 to 331	0	-	0	-
	Sol. DSS 3	24	332 to 355	0	-	0	-
3	Sol. DSS 1	14	300 to 313	10 call appearances			
	Sol. DSS 2	24	314 to 337				
	Sol. DSS 3	24	338 to 361				
4-5-6	Sol. DSS 1	24	300 to 323	0	-	0	-
	Sol. DSS 2	24	324 to 347	0	-	0	-
	Sol. DSS 3	24	348 to 371	0	-	0	-
7-8	Sol. DSS 1	16	300 to 315	8	410 to 417	0	-
	Sol. DSS 2	24	316 to 339	0	-	0	-
	Sol. DSS 3	0	-	0	-	24	200 to 223
9	Sol. DSS 1	0	-	0	-	24	200 to 223
	Sol. DSS 2	0	-	0	-	24	224 to 247
	Sol. DSS 3	0	-	0	-	24	248 to 271

Note: Solaris DSS are numbered 1 to 3 from left to right.

Remove an extension

Remove an extension

—

Enter extension number : ...

This extension number becomes available.

—

VALIDATION ———> Enter

PREVIOUS PAGE ———> F4

Remove an extension

Used to remove an extension so that the system will no longer recognize it at all.

Note: An extension can only be removed

- if the appropriate line board has been removed when alive,
- if the extension (dedicated, digital or S0 ISDN extension) has been disconnected.

Remove a trunk

Remove a trunk

Trunk numbers are included between
410 and 4..

Enter trunk number : 4..

If the trunks are ISDN-PRI or BRIs,
all the B-channels are removed.

Remove a trunk

Used to remove a trunk so that the system will no longer recognize it at all.

Note: A trunk can only be removed if the appropriate trunk board has been removed when alive.

Event report

```

                                Event report
                                -----
-
Date of start      : ../../.. ..h..m..

Event report criteria ..... 1

Real-time event report..... 2

Event report scheduled ouput..... 3

-----
-
Select option :                               .

VALIDATION                                —————> Enter

```

Date of start

Supplied by the system, it is the date of the last system start-up.

Important: The following parameters are intended for the system installer and manufacturer.

Option 1: See *Event report criteria*, page 11-14.

Option 2 : See *Real-time event report*, page 11-15.

Option 3 : See *Event report scheduled output*, page 11-16.

Event report criteria

Event report criteria

—

Name of calling thread

Type	save	diplay
NON-BLOCKING	.	.
BLOCKING	.	.
OS	.	.
LIMIT	.	.
EXPERT	.	.

Use Y/N, to activate or deactivate
a criterion.

—

VALIDATION —————> Enter

Name of calling thread

Enter 0 to 4 characters.

* = indiscriminate character.

For instance: f* gives the event report for all the calls with a name of calling thread beginning with f.

Type

save

display

Real-time event report

```

Real-time event report
-----
Display on PC ..... 1
Printer output ..... 2
                        validated : ...

Option 2 lets you know if the
printer output is validated or not.
-----
Select option : .
VALIDATION      -----> Enter

```


Data is displayed in scroll mode on the full screen.

```

Event report output
-----
./././..h..m..
./././..h..m..
./././..h..m..
./././..h..m..
./././..h..m..
./././..h..m..
./././..h..m..
./././..h..m..
-----
NEXT CALLS                               ==> Down
PREVIOUS CALLS                           ==> Up
PREVIOUS PAGE                             ==> F4

```

The event report output is displayed on successive pages. Use Down or Up to move from one page to another.



Event report scheduled output

Event report scheduled output

Display on PC 1

Printer output 2

Select option : .

VALIDATION —————> Enter

Event report output

.././.. ..h..m..

.././.. ..h..m..

.././.. ..h..m..

.././.. ..h..m..

.././.. ..h..m..

.././.. ..h..m..

.././.. ..h..m..

.././.. ..h..m..

.././.. ..h..m..

.././.. ..h..m..

NEXT CALLS —————> Down

PREVIOUS CALLS —————> Up

PREVIOUS PAGE —————> F4

United Kingdom

Analog CO-trunks

Analog CO-trunk board

The DC signaling mode on CO trunks is “loop calling - unguarded clearing”.

Power failure transfer board

It is a regulatory requirement that under powerfailure conditions, a proportion of analog CO-trunks must continue to have access to the Public Telephone Network.

In the UK, the power failure transfer board is **mandatory** in a system equipped with analog CO-trunk board(s).

Call charge detector board

In the UK, the 50 Hz call charge detector board should not be used.

Restriction

It is a regulatory requirement that all the extensions within a system must have emergency access.

In the UK, the class of restriction 11 should not be used.



A

Access to
 call forward off premises **6-5**
 Activate **7-4**
 Activate CRC **7-4**
 Add/Modify Extension nb-Calling party nb **9-17**
 Additional information **9-13**
 Administer
 time of day plans **10-5**
 Administered members **6-10, 6-12, 6-13, 9-27**
 Administering a class **10-3**
 Administration language **5-16**
 Allow access to override night service restriction **6-4**
 Analog CO trunk **7-3**
 Answering position **9-21, 9-24**
 Area code **9-18**
 Assign
 ISDN-DID trunks **9-15**
 time-of-day plan **6-4**
 Assigned destination **6-5**
 Attendant
 extension numbers **6-14**
 Authorization code **6-4**
 Auto-answer **6-3, 6-8, 9-12, 9-13**
 timeout interval **6-8**

B

Base Identification Code **5-12**
 BID. See base identification code
 Button assignments **6-7**

C

Call forward timer value **11-8**
 Call park timer value **11-8**
 Call transfer timer value **11-8**
 Call waiting indication **6-6**
 Calling party number **9-16, 9-17**
 Classes of restriction **10-3**
 Code
 cordless phone **5-13**
 Common access **9-28**

Configuration reports/Real-time CDR reports **5-6**
 Configure
 SOLARIS DSS **11-10**
 VEGA DSS **11-9**
 Connected to a host PBX **7-5**
 COR. See classes of restriction
 Cordless phone
 deregistration **5-14**
 Country code **5-15**
 Coverage point **9-21, 9-24**
 CPN number. See calling party number
 CT2 **5-12**

D

Date of start **11-13**
 Day service
 class of restriction **6-4**
 incoming destination **9-4**
 Deny access to
 extension button assignment **6-16**
 SOLARIS DSS button assignment **6-16**
 VEGA DSS button assignment **6-16**
 DID
 call distribution mode **6-9**
 coverage timeout intervals **9-10**
 number **9-12**
 Direct connection-Validate **6-6**
 Direct department calling **6-9**
 Display **11-14**
 language **6-6**
 Don't answer interval **9-4**

E

Exclusive hold timer value **11-8**
 Extension
 group **6-9**
 group number **6-9, 9-23**
 number **5-13, 6-2, 9-12, 9-17, 9-18, 9-21**
 numbers **9-19**
 Extensions **9-5, 9-7**

F

First

announcement **6-8**DID number in list **9-11, 9-14**digit **5-8**Flashhook interval **11-8**Forced first announcement **6-8****G**Group **9-3**name **6-11**number **9-24****H**

Host PBX

access code **7-5**flash length **11-8**Hunting delay interval **6-10****I**

Incoming

trunk groups **9-3**

Incoming destination

trunk group number **9-3**Interdigit timer **9-10**Intrusion timer value **11-8**

ISDN

BRI **7-3**PRI **7-3**ISDN-DID **9-15**

ISDN-subaddressing

coverage timers **9-19****L**Length of pre-recorded announcement **6-8**

List of

trunk numbers **7-5**Login password **2-3****M**Manufacturer's parameters **5-14**

Maximum number of

calls in queue **6-9**simultaneous forwarded calls **6-5**Mode **9-13****N**Name **5-13**

Name of

calling thread **11-14**group **6-9, 9-24**

Night service

class of restriction **6-4**incoming destination **9-6**

Number of

B-channels **7-4**bits **5-5**consecutive DID numbers **9-11**consecutive numbers in the list **9-14**digits **5-8**non-significant digits **9-10**significant digits **9-10**stop bits **5-5****O**

Outgoing

assignment **9-28**trunk groups **9-26****P**Parity **5-5**

Port

Configuration reports/Real-time CDR reports **5-**

6

Customized CDR overload alarm **5-6**
number **5-3, 6-3, 7-2, 7-6, 9-3, 9-15**

R

Recording code **6-11**
Re-initialize
 an extension **11-7**
Restricted **10-3**
Retrieval code **6-11**
Ringing
 cycle for external calls **6-5**
 several extensions at once **6-10**
RTC **7-3**

S

S0 Bus
 Length option **5-3**
Save **11-14**
Selective access **9-29**
Signaling mode **7-5**
Software **12-1**
 Identification **12-1**
 Upgrade **12-1**
Solaris DSS configuration **6-6**
Start **10-5**
Stop **10-5**
System
 AD plan **5-9**
 call waiting indication **6-15**

T

T0 **7-3**
T2 **7-3**
Terminal
 type **6-2**
Terminating extension group **6-9**
Time-of-day plan **9-13**
Timeout interval **6-6**
Transmission speed **5-5**

Trk non existent **5-4**
Trunk
 number **7-5, 7-6**
 type **7-6, 9-3, 9-15**
Type **11-14**
Type of
 redirection **9-22, 9-25**
 trunk **7-3, 7-5**

U

UM. See units of measurement
Uniform call distribution **6-9**
Units of Measurement **5-2**
Unrestricted **10-3**
User's name **6-3, 9-21**

V

Validate outset **5-10**
Vega DSS configuration **6-6**
Voice Services group **9-4, 9-6**
 number **6-11**

W

When the external ringer is active, incoming trunk
 calls ring the attendant console(s) **6-14**

X

Xon_Xoff **5-5**

